


Rear axle: differences between Spicer and ENV

If you look from behind, it is easy to see which axle you have.

Spicer has an inspection cover that is attached with 10 screws to the rear of the differential.

On the **ENV**, the differential has no rear inspection cover at all. It instead opens at the front of the differential.

Spicer



ENV

